

INSTRUCTIONS FOR USE EDGE PROTECTOR

Read the operating instructions carefully and keep them for future reference. Failure to observe the instructions may impair the safety function.

ATTENTION!

The edge protector is not a toy - keep it out of the reach of children.

This item is an aid to protect your child - it does not replace the duty of supervision by adults.

Only use the item for its intended purpose.

If you notice any defects, do not use the item.

Regularly check that it is securely fastened.

This product can provide protection for children up to the age of approx. 24 months. Do not underestimate the abilities and developmental leaps of your child.

Do not use the product on objects with a weak or easily removable surface.

Hoffenbach accepts no liability if the surface is damaged and will not replace the product if damage occurs.

MOUNTING THE CORNER GUARD

To minimize the risk of injury, it is recommended to mount the corner protector on the top and bottom edge of the table.

1. Wipe the surface with a dry cloth.
2. Test whether the corner protector is suitable for the corner of your table/shelf.
3. Apply the 3M adhesive strips to the corner protector.
4. Remove the top film from the adhesive strip.
5. Press all sides of the corner protector firmly onto the desired area of the table for 60 seconds.
6. Allow the corner protector to rest for 24 hours. The adhesive must dry well to achieve the best possible bonding performance.

FITTING THE EDGE PROTECTION

1. First install the corner protectors on all corners as instructed above.
2. Measure the distance of the edge between two corner protectors and cut a suitable piece from the edge protector using a carpet knife or scissors.
3. Wipe the edge surface with a dry cloth.
4. Also cut the 3M adhesive tape to size: two strips per edge protector. Now stick one strip of 3M adhesive tape on the inside of each edge protector.
5. Remove the adhesive protection and straighten the edge protector.
6. Press both sides of the edge protector firmly along the entire length for 60 seconds.

REMOVE

Corner protector: Grasp both ends of the corner protector and slowly and steadily pull both ends towards the center. *Edge protection:* Grasp one end of the edge protection and pull it slowly and steadily towards the other end. If any adhesive residue remains on the wood, use a little vegetable oil and your fingertip in a circular motion until the adhesive residue has come off. Now use a paper towel to remove all residues. If there is still residue, repeat the process. On other surfaces such as glass / metal, you can also use alcohol to remove the residue. However, test the surface first to ensure that the alcohol does not damage the surface. We do not recommend using alcohol on wooden surfaces.

CARE

Wipe the surface with a damp cloth. Do not use soap, alcohol or other cleaning agents. Then wipe again with a dry cloth. Keep the protection dry and oil-free.

These instructions for use apply to the following model numbers: 300101, 300102, 300103

Brand: Hoffenbach

Packaging dimensions: 35 x 29,6 x 3,1 cm

Item weight: 400 g

Scope of delivery: 6.2 meter bumper, 8 corner protectors

Viktor Bulchak

Sole proprietorship

Nachtweide 5B

38122 Braunschweig

Germany

E-Mail: v.bulchak@gmail.com

www.hoffenbach.net