

Operating instructions for socket outlet protection

Please read these instructions carefully before installation and use to ensure the safety function of the product. Keep these instructions for future reference. Failure to observe the instructions may impair the safety function.

Installation instructions

1. Switch off the circuit.
2. Clean any dirt from the socket.
3. Remove the protective film from the back of the socket outlet fuse
4. Press the socket outlet fuse firmly into the socket outlet for at least 60 seconds.
5. Wait 24 hours.
6. Before activating the circuit, please check the function of the socket outlet protection. Switch the circuit back on after checking the functionality.

Usage

1. Unlock the fuse by inserting the plug with both pins into the socket and turning it according to the direction of the arrow on the fuse.
 2. As soon as the lock is released, the plug can be fully inserted into the socket.
- Caution! If used regularly, please check the function regularly.

Disassembly

1. Switch off the circuit.
2. Heat the socket fuse with a hairdryer for 60 seconds.
3. Carefully remove the socket protection using a blunt, non-conductive object. Be careful not to damage the socket outlet.

Safety instructions

- Only use the socket outlet protector for its intended purpose. Observe the safety instructions.
- This product can provide protection for children up to the age of about 24 months. Take your child's abilities and developmental leaps into account. If your child is able to operate the socket safety device independently, it should no longer be used.
- The product must be installed professionally. If in doubt, get help from appropriate specialists.
- Keep the socket outlet fuse out of the reach of children. The safety article is not a toy.
- Check plugs and socket protectors regularly to ensure that they are still seated correctly. Loose plugs pose a fire hazard.
- Do not use the socket outlet fuse if you notice any defects or discoloration.
- The safety article is only suitable for indoor domestic use. Each socket outlet fuse is intended for single use, as the adhesive strips no longer guarantee a firm hold once they have been removed.
- This safety device serves as an aid for your child and does not replace the duty of supervision. Never leave your child unattended near electrical appliances or installations.
- Each socket protector may only be used once, as the adhesive strips no longer guarantee a firm hold once they have been removed.

Viktor Bulchak
Nachtweide 5B
38122 Braunschweig
Germany
E-Mail: v.bulchak@gmail.com
www.hoffenbach.net

Model number: 400300
Brand: Hoffenbach
Packaging dimensions: 19.9 x 13.9 x 1 cm
Item weight: 70 g
Scope of delivery: 20x socket protectors