

Operating instructions for the socket outlet protection

Please read these instructions carefully before installation and use to ensure the safety function of the product. Keep these instructions for future reference. Failure to observe the instructions may impair the safety function.

Installation and operating instructions

1. Insert the fuse into the socket. The socket is secured!
2. Insert the plug into the larger openings in the socket cover.
3. Turn it in the direction of the smaller openings and then pull it out.
4. The socket outlet can be used again.

Safety instructions

- Only use the socket outlet protector for its intended purpose. Observe the safety instructions.
- This product can protect children up to the age of about 24 months. Take your child's abilities and developmental leaps into account. Once your child is able to operate the socket protector independently, it should no longer be used.
- The product must be installed correctly. If in doubt, get help from appropriate specialists.
- Keep the socket outlet fuse out of the reach of children. The fuse is not a toy.
- Check plugs and socket fuses regularly to ensure that they are correctly seated. Loose plugs pose a fire hazard.
- The safety article is only suitable for indoor domestic use.
- Do not use the socket outlet safety device if you notice any defects or discoloration.
- This safety device serves as an aid for your child and does not replace the duty of supervision. Never leave your child unattended near electrical appliances or equipment.

Viktor Bulchak
Nachtweide 5B
38122 Braunschweig
Germany
E-Mail: v.bulchak@gmail.com
www.hoffenbach.net

Model number: 400102, 400204
Brand: Hoffenbach
17,5 x 14,5 x 1,5 cm
Item weight: 70 g
Scope of delivery: 20x socket protectors